



E-mail: mail@brack-case.ch

Peter Brack **B**

CH-5622 Waltenschwil Kirchweg 1 Telefon 056/ 622 54 58

Fax 056/ 621 82 13

Repair instructions - neck girdle belt

- In the throat block pack, remove the foam plug and unscrew the countersunk plastic screw
- Remove the throat block
- Unscrew the girdle plate screws from outside
- Pass the screw through the girdle plate, small ring, foam plate and white securing ring, insert into the boring and tighten
- Insert the throat block again.

Components:

- Girdle plate
- Small ring
- Foam plate
- 2 screws
- Plastic securing ring